

01 / COLLECTION GUIDE

KENCLEEF

Clear Paint Protection Film

Clear protection for the paint you chose.

START WITH THE SURFACE

An introduction to the collection and the questions that help define a suitable installation.

AI visual concept. Actual film appearance and approved product information require a physical sample and current documents.

02 / PURPOSE & APPEARANCE

What this collection is for.

KENCLEEF is clear paint protection film for drivers who want their original paint color to stay visible. Choose the panels you want to cover, then ask an installer to confirm the film, the panel boundaries and the finish on your vehicle.



Illustrative AI visual. It does not show a measured KENCLA installation.

SURFACE

Exterior painted body panels

APPEARANCE

Clear film with the underlying paint color visible

03 / THE DETAILS

Look closer at the finish.

The right comparison happens on the surface, in the light and at the edges that matter to you.

01

See the finish up close

Compare a physical sample on a surface close to your own paint. Look across a body line in daylight, then examine the reflection and the edge at an angle. This is where you can judge how the film and the paint look together.

02

Choose the panels first

Start with the areas you want to cover and ask for each panel to be listed in the quote. The exact edges and boundaries depend on the vehicle and the installer's plan.

03

Review the paint condition

Tell the installer about repainted panels, chips, previous film or a coating. Ask what preparation the paint needs and which areas should be reviewed before installation.

04 / COVERAGE

Plan the area you want to address.

Use these as conversation starters. An installer must define the exact film, edges and eligible surface.

01

Front panels

Ask whether the bumper, hood, front fenders and mirror caps can be included. Confirm whether the hood and fenders would be fully or partly covered.

02

Selected panels

Identify the areas you want to cover, such as door edges or rocker panels. Ask the installer which pieces can be covered and where the film will end.

03

Full body

Request an itemized list of the proposed painted panels, including exclusions and edges. Discuss windshield and roof glass separately.

05 / BEFORE INSTALLATION

A clear next step.

Bring the vehicle details, compare an applicable physical sample and request the current approved documents for the exact film.

Can I keep the paint color I have now?

KENCLEEF is the clear film family. View a sample against your paint to assess the reflection, surface appearance and film edge before choosing coverage.

Can I cover just the front?

Ask the installer for an itemized front coverage quote. Confirm which panels are included and whether each one would be fully or partly covered.

What if a panel was repainted?

Tell the installer when the panel was repainted and share any refinishing information you have. They can review the condition and confirm the requirements for the selected model.

PRODUCT INFORMATION STATUS

This guide is an overview. Measured KENCLA model specifications, saleable options and warranty terms are not established by this document. Ask for the current approved data for the exact film.

CONTACT GLASSTINT

glasstint.com/en/contact/write