

03 / COLLECTION GUIDE

KENCLOR

Color Paint Protection Film

Choose the color in the light you drive in.

START WITH THE SURFACE

An introduction to the collection and the questions that help define a suitable installation.

AI visual concept. Actual film appearance and approved product information require a physical sample and current documents.

02 / PURPOSE & APPEARANCE

What this collection is for.

KENCLOR is color paint protection film. Compare an approved physical swatch on the vehicle in daylight and shade, then decide whether the new color belongs across the body or on selected panels. Confirm the actual shade and market availability with an installer.



Illustrative AI visual. It does not show a measured KENCLA installation.

SURFACE

Exterior painted body panels

APPEARANCE

Color and finish selected from approved film swatches

03 / THE DETAILS

Look closer at the finish.

The right comparison happens on the surface, in the light and at the edges that matter to you.

01

Start with a physical swatch

Ask which shades and finishes are approved in your market. View the physical swatch in daylight and shade against the vehicle, then confirm its shade code with the installer.

02

Follow the color around the vehicle

Assess the color on broad panels, body lines and deep contours. Compare the planned finish next to trim and any painted areas you intend to leave visible.

03

Agree on where the new color ends

Ask the installer to show panel returns, openings, seams and visible edges before approving the quote. Record the chosen shade and finish with the final panel list.

04 / COVERAGE

Plan the area you want to address.

Use these as conversation starters. An installer must define the exact film, edges and eligible surface.

01

Full body color

Review all painted panels in the scope and identify whether openings, returns and recesses are included or excluded.

02

Selected panels

Choose which panels will change color. View a sample alongside the existing paint and trim before confirming the combination.

03

Accent areas

Show the installer the exterior painted area you want to highlight and ask them to confirm the substrate, boundaries and feasible seams.

05 / BEFORE INSTALLATION

A clear next step.

Bring the vehicle details, compare an applicable physical sample and request the current approved documents for the exact film.

Will the color look like it does on my screen?

The screen image helps you shortlist options. Check the approved physical swatch on the vehicle in daylight and shade before you order.

Are door jambs included in a full body installation?

Ask the installer to identify every opening and return in the quote. Confirm where the underlying paint may still be visible.

How should I record the color for a future repair?

Keep the exact shade code, finish, installation record and any batch reference supplied by the installer. Ask how replacement film availability and color matching will be checked.

PRODUCT INFORMATION STATUS

This guide is an overview. Measured KENCLA model specifications, saleable options and warranty terms are not established by this document. Ask for the current approved data for the exact film.

CONTACT GLASSTINT

glasstint.com/en/contact/write